# 0Q0 - Bear Valley

#### Airport details

State California

Country United States of America

Region

Elevation 7073ft (2156m)

Timezone GMT -8

Coordinates 38.45517, -120.04391

Type land ICAO code 0Q0 IATA code n/a FAA code 73CA

#### Runway info

Runway 01 / 19

 $\begin{array}{ll} \text{length} & 799\text{m (2621ft)} \\ \text{bearing} & 37^{\circ} \, / \, 217^{\circ} \\ \text{width} & 15\text{m (50ft)} \end{array}$ 

surface dirt

blast zone 162m (531ft) / 0m (0ft)

#### Communication

No airport communication available for 0Q0

#### Nearby beacons

code	identifier	dist	bearing	frequency
HNW	HANGTOWN (PLACERVILLE) VOR/DME	36.8	290.9°	115.50
SWR	SQUAW VALLEY(SOUTH LAKE T VOR/DME	44.8	342.7°	113.20
LIN	LINDEN VOR/DME	50.7	248.3°	114.80
MOD	MODESTO VOR/DME	65.8	227.8°	114.60

### Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only