

# 2H0 - Shelbyville - Shelby County

---

## Airport details

State	Illinois
Country	United States of America
Region	K5
Elevation	618ft (188m)
Timezone	GMT -6
Coordinates	39.41060, -88.84542
Type	land
ICAO code	2H0
IATA code	n/a
FAA code	2H0

## Runway info

Runway 18 / 36	
length	1251m (4104ft)
bearing	180° / 360°
width	23m (75ft)
surface	asphalt
Runway 14 / 32	
length	857m (2812ft)
bearing	132° / 312°
width	55m (180ft)
surface	grass
displacement threshold	0m (0ft) / 144m (472ft)
Runway 04 / 22	
length	792m (2598ft)
bearing	47° / 227°
width	55m (180ft)
surface	grass
displacement threshold	75m (246ft) / 0m (0ft)

## Communication

Shelby County CTAF/UNICOM	122.800
Shelby County CTAF/UNICOM	122.800
Shelby County CTAF/UNICOM	122.800
Shelby County CTAF/UNICOM	122.800
Shelby County CTAF/UNICOM	122.800
Shelby County KANSAS CITY APPROACH	124.300
Shelby County KANSAS CITY APPROACH	124.300

Shelby County KANSAS CITY APPROACH	124.300
Shelby County KANSAS CITY APPROACH	124.300
Shelby County KANSAS CITY APPROACH	124.300
Shelby County KANSAS CITY DEPARTURE	124.300
Shelby County KANSAS CITY DEPARTURE	124.300
Shelby County KANSAS CITY DEPARTURE	124.300
Shelby County KANSAS CITY DEPARTURE	124.300
Shelby County KANSAS CITY DEPARTURE	124.300

## Nearby beacons

<b>code</b>	<b>identifier</b>	<b>dist</b>	<b>bearing</b>	<b>frequency</b>
SYZ	SHELBYVILLE NDB	0.2	155.4°	365
AXC	ADDERS VORTAC	19.6	358°	117.20
DE	ELWIN (DECATUR) NDB	23.3	344°	275
VLA	VANDALIA VOR/DME	24	225°	114.30
MTO	DME	26.2	83.1°	109.40
BIB	BIBLE GROVE VORTAC	33.9	143.4°	109
CJ	CALDE (SPRINGFIELD) NDB	41.5	297.1°	240
GRE	GREENVILLE NDB	42.4	222.4°	233
CM	VEALS (CHAMPAIGN/URBANA) NDB	45.3	50°	407
CMI	CHAMPAIGN VORTAC	45.7	42.3°	110
LQ	LICOL (SPRINGFIELD) NDB	46.1	303.4°	375
SPI	SPINNER (SPRINGFIELD) VORTAC	46.3	297.2°	112.70
SP	HUSKK (SPRINGFIELD) NDB	47.5	291.6°	382
AAA	ABRAHAM (LINCOLN) NDB	50.4	326.6°	329
OLY	OLNEY NDB	52	135.8°	272
ENL	CENTRALIA VORTAC	61.2	197.5°	115
SAM	SAMSVILLE VOR/DME	65.9	140.6°	116.60
JD	GOOEY (BELLEVILLE) NDB	69.8	223.7°	385

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only