

8TA0 - Floresville - John B Connally Ranch

Airport details

State	Texas
Country	United States of America
Region	
Elevation	527ft (161m)
Timezone	GMT -6
Coordinates	29.13837, -98.28150
Type	land
ICAO code	8TA0
IATA code	n/a
FAA code	8TA0

Runway info

Runway 11 / 29	
length	1140m (3740ft)
bearing	117° / 297°
width	18m (60ft)
surface	asphalt

Communication

No airport communication available for 8TA0

Nearby beacons

code	identifier	dist	bearing	frequency
SSF	STINSON (SAN ANTONIO) VOR	11.1	306.5°	108.40
KSY	KELLY (SAN ANTONIO) TACAN	21.8	310.2°	112
RND	RANDOLPH VORTAC	22.8	359.4°	112.30
DHK	RANDOLPH TACAN	23.9	1.9°	109.90
SAT	SAN ANTONIO VORTAC	31.7	340.4°	116.80
AN	ALAMO (SAN ANTONIO) NDB	31.9	328.4°	368
HHH	DEVINE NDB	34.5	269.9°	359
THX	THREE RIVERS VORTAC	38.6	168.3°	111.40
RU	GARYS (AUSTIN) NDB	52.2	22°	272
COT	COTULLA VORTAC	59.9	231°	115.80
CSI	CENTER POINT (KERRVILLE) VORTAC	67.7	310°	117.50

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only