

95VA - Danville - Buck Hollar

Airport details

State	Virginia
Country	United States of America
Region	
Elevation	450ft (137m)
Timezone	GMT -5
Coordinates	36.62248, -79.35686
Type	land
ICAO code	95VA
IATA code	n/a
FAA code	95VA

Runway info

Runway 17 / 35	
length	366m (1201ft)
bearing	159° / 339°
width	23m (75ft)
surface	grass

Communication

No airport communication available for 95VA

Nearby beacons

code	identifier	dist	bearing	frequency
DAN	DANVILLE VOR	3.3	159.3°	113.10
SBV	SOUTH BOSTON VORTAC	16.7	81.2°	110.40
SIF	SLAMMER (REIDSVILLE) NDB	24.3	239.3°	423
UV	BALES (MARTINSVILLE) NDB	27	266.6°	396
HUR	PERSON (ROXBORO) NDB	27.2	143.2°	220
LYH	LYNCHBURG VOR/DME	38.4	10.7°	109.20
LY	BOJAR (LYNCHBURG) NDB	38.8	10°	385
HB	ALAMM NDB	40.2	199.4°	361
HXO	HUNTSBORO (OXFORD) NDB	40.5	113.5°	271
VIT	VINTON (ROANOKE) NDB	43	317.9°	277
GSO	GREENSBORO VORTAC	45.8	227°	116.20
LIB	LIBERTY VORTAC	50.2	197.5°	113
IN	REENO (WINSTON SALEM) NDB	51.3	235.7°	317
ODR	WOODRUM (ROANOKE) VOR	51.6	318.4°	114.90
LE	LEEVEY (RALEIGH/DURHAM) NDB	51.8	137.5°	350
RDU	RALEIGH-DURHAM VORTAC	52.9	142.5°	117.20

ROA ROANOKE VOR/DME 55.1 315.2° 109.40

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only