

99KY - Danville - Gravity Zero

Airport details

State	Kentucky
Country	United States of America
Region	
Elevation	859ft (262m)
Timezone	GMT -5
Coordinates	37.65576, -84.69234
Type	land
ICAO code	99KY
IATA code	n/a
FAA code	99KY

Runway info

Runway 10 / 28	
length	366m (1201ft)
bearing	96° / 276°
width	15m (50ft)
surface	grass

Communication

No airport communication available for 99KY

Nearby beacons

code	identifier	dist	bearing	frequency
DVK	GOODALL (DANVILLE) NDB	5.8	222.1°	311
LE	BLAYD (LEXINGTON) NDB	19.9	5.4°	242
HYK	LEXINGTON VOR/DME	21.3	35.2°	112.60
GN	BRIDL (LEXINGTON) NDB	29.4	21.5°	340
FFT	FRANKFORT VOR	33.2	337.6°	109.40
CDX	CUMBERLAND RIVER (SOMERSET) NDB	39.6	179°	388
IOB	MOUNT STERLING NDB	41.5	60.3°	210
LOZ	LONDON VOR/DME	46.5	136.9°	116.55
EWO	NEW HOPE VOR/DME	46.7	268.6°	110.80
IIU	LOUISVILLE VORTAC	49.8	296.8°	114.80
LK	LAANG (LOUISVILLE) NDB	53.3	297.4°	414
BQM	(LOUISVILLE) DME	57.5	300.5°	112.20
FLM	FALMOUTH VOR/DME	62.3	21°	117

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only