

BIAR - Akureyri

Airport details

State	Northeastern Region (Iceland)
Country	Iceland
Region	BI
Elevation	4ft (1m)
Timezone	GMT +0
Coordinates	65.65667, -18.07195
Type	land
ICAO code	BIAR
IATA code	AEY
FAA code	n/a

Runway info

Runway 01 / 19	
length	2394m (7854ft)
bearing	349° / 169°
width	45m (148ft)
surface	asphalt

Communication

Akureyri TWR	118.200
Akureyri TWR	118.200
Akureyri TWR	118.200
Akureyri TWR	118.200
Akureyri RADAR	118.700
Akureyri RADAR	118.700
Akureyri RADAR	118.700
Akureyri RADAR	118.700

Approach frequencies

LOC	01	111.9	18.00mi
ILS-cat-I	01	108.9	18.00mi
ILS-cat-I	19	110.5	18.00mi
5.3° GS	01	108.9	18.00mi
3.4° GS	19	110.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
MOB	MOB TACAN	1.2	168.8°	114.80

OE	ODDEYRI (AKUREYRI) NDB	1.7	349.1°	415
KN	KRISTNES (AKUREYRI) NDB	4.2	169.3°	364
AR	AKUREYRI NDB	5.9	349.9°	334
AKI	AKUREYRI VOR/DME	6.4	33.3°	113.60
TO	TORFUR (AKUREYRI) NDB	9.5	206.8°	324
HJ	HJALTEYRI (AKUREYRI) NDB	12	328.4°	319
GA	GARDUR (HUSAVIK) NDB	20	70°	377
NB	BOTN (AKUREYRI) NDB	20.6	213.8°	387
HS	HUSAVIK NDB	22.5	66.8°	329

Departure and arrival routes

Transition altitude 7000ft

SID end points	distance	outbound direction
RW01		
UTIS2A	22.5	73°
MAME1A	18.1	87°
ASKU1B, ASKU1A	31.7	233°
PERU1A, PERU1B	25.5	256°
RW19		
RETU1D	13.1	105°
JARI1C, JARI1D, JARI1E	27.1	170°
ASKU1D, ASKU1C, ASKU1E	31.7	233°
PERU1D	25.5	256°

STAR starting points	distance	inbound direction
RW19		
PERU1N	25.5	76°
AFPA1M	20.2	100°
BEZI1M	25.5	117°
CUBA1M	29.6	142°
DORF1M	28.7	160°
UTIS1N, UTIS1M	22.5	253°
MAME1M, MAME1N	18.1	267°
PEXI1N, PEXI1M	15.1	355°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only