

# CYFB - Iqaluit

---

## Airport details

State	Nunavut
Country	Canada
Region	CY
Elevation	109ft (33m)
Timezone	GMT -5
Coordinates	63.75657, -68.55612
Type	land
ICAO code	CYFB
IATA code	YFB
FAA code	n/a

## Runway info

Runway 16 / 34	
length	2623m (8606ft)
bearing	114° / 294°
width	61m (200ft)
surface	asphalt
blast zone	64m (210ft) / 74m (243ft)

## Communication

Iqaluit FSS	126.700
Iqaluit FSS	126.700
Iqaluit FSS	126.700
Iqaluit FSS	126.700
Iqaluit Iqaluit Radio	122.200
Iqaluit Iqaluit Radio	122.200
Iqaluit Iqaluit Radio	122.200
Iqaluit Iqaluit Radio	122.200
Iqaluit Montreal Center	134.550
Iqaluit Montreal Center	134.550
Iqaluit Montreal Center	134.550
Iqaluit Montreal Center	134.550
Iqaluit Montreal Center	134.550
Iqaluit Montreal Center	134.550
Iqaluit Montreal Center	134.550
Iqaluit Montreal Center	134.550

## Approach frequencies

ILS-cat-I	34	109.9	18.00mi
-----------	----	-------	---------

3° GS      34      109.9      18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
YFY	FROBAY (IQALUIT) NDB	1.4	160.4°	204
YFB	FROBAY (IQALUIT) VOR	2.3	100.2°	117.40

## Departure and arrival routes

Transition altitude      18000ft  
Transition level      18000ft

SID end points		distance	outbound direction
RW16			
	CYFB5	177.6	246°
RW34			
	CYFB5	177.6	246°

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only