

EFKU - Kuopio / Siilinjärvi - Kuopio

Airport details

State	Eastern Finland
Country	Finland
Region	EF
Elevation	323ft (98m)
Timezone	GMT +2
Coordinates	63.00861, 27.79445
Type	land
ICAO code	EFKU
IATA code	KUO
FAA code	n/a

Runway info

Runway 15 / 33	
length	2793m (9163ft)
bearing	137° / 317°
width	60m (197ft)
surface	asphalt
blast zone	150m (492ft) / 97m (318ft)

Communication

Kuopio ATIS	113.000
Kuopio ATIS	113.000
Kuopio ATIS	113.000
Kuopio ATIS	113.000
Kuopio TWR	120.150
Kuopio TWR	119.700
Kuopio TWR	119.700
Kuopio TWR	120.150
Kuopio TWR	119.700
Kuopio TWR	120.150
Kuopio TWR	120.150
Kuopio TWR	119.700
Kuopio APP	130.600
Kuopio APP	119.700
Kuopio APP	130.600
Kuopio APP	119.700
Kuopio APP	119.700
Kuopio APP	130.600
Kuopio APP	130.600
Kuopio APP	119.700

Approach frequencies

ILS-cat-I	33	110.3	18.00mi
3° GS	33	110.3	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
VEH	VEHKAA (KUOPIO) VOR/DME	1.8	146°	113

Departure and arrival routes

Transition altitude 5000ft

SID end points

	distance	outbound direction
--	----------	--------------------

RW15

ETEN3C	28.6	101°
ATLU3C	26.5	183°
ASTU3C	28.6	217°
NISP3C	25.4	246°
UGLU3C	24.7	339°

RW33

ETEN3E	28.6	101°
ATLU3E	26.5	183°
ASTU3E	28.6	217°
NISP3E	25.4	246°
UGLU3E	24.7	339°

STAR starting points

	distance	inbound direction
--	----------	-------------------

RW15

ATLU4F	26.5	3°
NISP3F	25.4	66°
UGLU2F	24.7	159°
ETEN4F	28.6	281°

RW33

ATLU2D	26.5	3°
NISP2D	25.4	66°
UGLU2D	24.7	159°
ETEN2D	28.6	281°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
ATLU2D	GILUV	VHF	right	146 (326)°	> 2700ft	1.0min timed	230
ATLU4F	BADMA	VHF	left	326 (146)°	> 2700ft	1.0min timed	230
ETEN2D	GILUV	VHF	right	146 (326)°	> 2700ft	1.0min timed	230
ETEN4F	BADMA	VHF	left	326 (146)°	> 2700ft	1.0min timed	230
NISP2D	GILUV	VHF	right	146 (326)°	> 2700ft	1.0min timed	230

NISP3F	BADMA	VHF	left	326 (146)°	> 2700ft	1.0min timed	230
UGLU2D	GILUV	VHF	right	146 (326)°	> 2700ft	1.0min timed	230
UGLU2F	BADMA	VHF	left	326 (146)°	> 2700ft	1.0min timed	230

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only