

EGWE - Henlow - Raf Henlow

Airport details

State	England
Country	United Kingdom
Region	EG
Elevation	168ft (51m)
Timezone	GMT +0
Coordinates	52.01955, -0.30182
Type	land
ICAO code	EGWE
IATA code	n/a
FAA code	n/a

Runway info

Runway 02 / 20	
length	1319m (4327ft)
bearing	28° / 208°
width	46m (151ft)
surface	grass
Runway 13 / 31	
length	1194m (3917ft)
bearing	117° / 297°
width	50m (164ft)
surface	grass
displacement threshold	0m (0ft) / 41m (135ft)
Runway 08R / 26L	
length	1101m (3612ft)
bearing	85° / 265°
width	50m (164ft)
surface	grass
displacement threshold	0m (0ft) / 80m (262ft)

Communication

No airport communication available for EGWE

Nearby beacons

code	identifier	dist	bearing	frequency
LUT	LUTON NDB	7.7	158.4°	345
CIT	CRANFIELD NDB	11.5	293.4°	850
BKY	BARKWAY VOR/DME	13.5	94.6°	116.25
BPK	BROOKMANS PARK VOR/DME	17.7	144.1°	117.50

BNN	BOVINGDON VOR/DME	19.8	220.2°	113.75
CAM	CAMBRIDGE NDB	21.2	68.4°	332
HEN	HENTON NDB	23.9	241.9°	433
CHT	CHILTERN NDB	25.1	208.6°	277
WCO	WESTCOTT NDB	26.4	255.8°	335
LAM	LAMBOURNE VOR/DME	28	129.4°	115.60
DTY	DAVENTRY VOR/DME	31.4	281.1°	116.40
LON	LONDON VOR/DME	32.5	197.1°	113.60
BUR	BURNHAM NDB	33.1	216.8°	421
LCY	LONDON CITY NDB	33.8	144.3°	322
MLD	MILDENHALL TACAN	35.6	66.4°	115.90
WIT	WITTERING TACAN	36	341.4°	117.60
BSO	BENSON TACAN	38.3	243°	110
LKH	LAKENHEATH TACAN	38.9	65.5°	110.20
WOD	WOODLEY NDB	40.2	225.5°	352
EPM	EPSOM NDB	42.1	185.7°	316
BIG	BIGGIN VOR/DME	43.2	153.9°	115.10
OCK	OCKHAM VOR/DME	43.2	191.4°	115.30
LE	LEICESTER NDB	44.3	308.6°	383
SND	SOUTHEND NDB	45.7	113.8°	362
WTZ	WATTISHAM TACAN	46.2	85.2°	109.30
BLC	DME	46.4	217.9°	116.20
BLK	BLACKBUSHE NDB	46.4	217.9°	328
CPT	COMPTON VOR/DME	46.5	240°	114.35
MAM	MARHAM TACAN	49.2	53.9°	108.70
ODH	ODIHAM TACAN	53	219.4°	109.60
DET	DETLING VOR/DME	54.4	128.5°	117.30
CLN	CLACTON VOR/DME	54.6	96.7°	114.55
EME	EAST MIDLANDS NDB	58.7	312.3°	353
MID	MIDHURST VOR/DME	59.2	198.5°	114
HLS	DME	62.9	132.2°	115.95
LSH	HEADCORN (LASHENDEN) NDB	62.9	132.2°	340
NWI	NORWICH NDB	70.5	67.5°	342

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only