

EICK - Cork

Airport details

State	County Cork
Country	Ireland
Region	EI
Elevation	501ft (153m)
Timezone	GMT +0
Coordinates	51.84139, -8.49111
Type	land
ICAO code	EICK
IATA code	ORK
FAA code	n/a

Runway info

Runway 07 / 25	
length	1307m (4288ft)
bearing	72° / 252°
width	45m (148ft)
surface	concrete
blast zone	0m (0ft) / 12m (39ft)
Runway 16 / 34	
length	2131m (6991ft)
bearing	149° / 329°
width	45m (148ft)
surface	asphalt
blast zone	35m (115ft) / 0m (0ft)

Communication

Cork Cork ATIS	120.925
Cork Cork Twr	121.700
Cork Cork Twr	119.300
Cork Cork Grd	121.850
Cork Cork ATIS	120.925
Cork Cork Twr	121.700
Cork Cork Twr	119.300
Cork Cork Grd	121.850
Cork Cork ATIS	120.925
Cork Cork Twr	121.700
Cork Cork Twr	119.300
Cork Cork Grd	121.850
Cork Cork ATIS	120.925
Cork Cork Grd	121.850
Cork Cork Twr	119.300

Cork Cork Twr	121.700
Cork Cork App	119.900
Cork Cork App	119.900
Cork Cork App	119.900
Cork Cork App	119.900

Approach frequencies

ILS-cat-II	16	109.9	18.00mi
ILS-cat-I	34	109.15	18.00mi
3° GS	34	109.15	18.00mi
3° GS	16	109.9	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
CRK	CORK VOR/DME	0.1	256°	114.60
FOY	FOYNES NDB	50.6	315.8°	395
SHA	SHANNON VOR/DME	54.7	335.8°	113.30
OL	SHANNON NDB	55.8	339.8°	339

Departure and arrival routes

Transition altitude 5000ft

SID end points	distance	outbound direction
RW07		
TISM1M, TISM1P	24.9	58°
VAPA1M, VAPA1P	24.9	87°
GOTE1M, GOTE1P	24.9	91°
ELTI1P, ELTI1M	24.9	98°
ERTE1M, ERTE1P	23.2	123°
ORTO1M, ORTO1P	35.0	161°
SOVI1M, SOVI1P	24.9	190°
KURU1P, KURU1M	24.1	336°
RW16		
TISM1Q, TISM1S	24.9	58°
VAPA1S, VAPA1Q	24.9	87°
GOTE1Q, GOTE1S	24.9	91°
ELTI1S, ELTI1Q	24.9	98°
ERTE1S	23.2	123°
ORTO1S	35.0	161°
SOVI1S	24.9	190°
KURU1S, KURU1Q	24.1	336°
RW25		
TISM1L, TISM1K	24.9	58°
VAPA1L, VAPA1K	24.9	87°
GOTE1L, GOTE1K	24.9	91°

	ELTI1K, ELTI1L	24.9	98°
	ERTE1K, ERTE1L	23.2	123°
	ORTO1L, ORTO1K	35.0	161°
	SOVI1K, SOVI1L	24.9	190°
	KURU1L, KURU1K	24.1	336°
RW34			
	TISM1T, TISM1N	24.9	58°
	VAPA1N, VAPA1T	24.9	87°
	GOTE1N, GOTE1T	24.9	91°
	ELTI1T, ELTI1N	24.9	98°
	ERTE1T, ERTE1N	23.2	123°
	ORTO1N	35.0	161°
	SOVI1N	24.9	190°
	KURU1N	24.1	336°

STAR starting points

RW07

	distance	inbound direction
SOVI1F	24.9	10°
KURU1F	24.1	156°
TISM1F	24.9	238°
VAPA1F	24.9	267°
GOTE1F	24.9	271°
ELTI1F	24.9	278°
ERTE1F	23.2	303°
ORTO1F	35.0	341°

RW16

SOVI1R	24.9	10°
KURU1R	24.1	156°
TISM1R	24.9	238°
VAPA1R	24.9	267°
GOTE1R	24.9	271°
ELTI1R	24.9	278°
ERTE1R	23.2	303°
ORTO1R	35.0	341°

RW25

SOVI1H	24.9	10°
KURU1H	24.1	156°
TISM1H	24.9	238°
VAPA1H	24.9	267°
GOTE1H	24.9	271°
ELTI1H	24.9	278°
ERTE1H	23.2	303°
ORTO1H	35.0	341°

RW34

SOVI1G	24.9	10°
KURU1G	24.1	156°
TISM1G	24.9	238°
VAPA1G	24.9	267°

GOTE1G	24.9	271°
ELTI1G	24.9	278°
ERTE1G	23.2	303°
ORTO1G	35.0	341°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only