

ENKR - Kirkenes - Kirkenes Høybukthmoen

Airport details

State	Finnmark
Country	Norway
Region	EN
Elevation	283ft (86m)
Timezone	GMT +1
Coordinates	69.72500, 29.88778
Type	land
ICAO code	ENKR
IATA code	KKN
FAA code	n/a

Runway info

Runway 06 / 24	
length	2098m (6883ft)
bearing	82° / 262°
width	45m (148ft)
surface	asphalt
displacement threshold	56m (184ft) / 442m (1450ft)

Communication

Kirkenes Høybukthmoen ATIS	118.025
Kirkenes Høybukthmoen ATIS	118.025
Kirkenes Høybukthmoen ATIS	118.025
Kirkenes Høybukthmoen ATIS	118.025
Kirkenes Høybukthmoen KIRKENES TWR	120.350
Kirkenes Høybukthmoen KIRKENES TWR	120.350
Kirkenes Høybukthmoen KIRKENES TWR	120.350
Kirkenes Høybukthmoen KIRKENES TWR	120.350

Approach frequencies

ILS-cat-I	23	110.3	18.00mi
3.4° GS	23	110.3	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
KIK	KIRKENES VOR/DME	0.3	266.3°	112
VD	VADSO NDB	20.4	359.1°	342
BX	BATSFJORD NDB	53.1	348.7°	348

Departure and arrival routes

Transition altitude 7000ft

SID end points	distance	outbound direction
RW05		
VANO2E	18.4	155°
SIVN2E	16.3	257°
VADL2E	22.7	271°
ROVA2E	28.5	273°
SDA2E	48.2	286°
RW23		
VANO1F	18.4	155°
SIVN1F	16.3	257°
VADL1F	22.7	271°
ROVA1F	28.5	273°
SDA1F	48.2	286°

STAR starting points	distance	inbound direction
RW05		
VADL1R	22.7	91°
ROVA1R	28.5	93°
SDA1R	48.2	106°
VANO1R	18.4	335°
RW23		
SIVN1Q	16.3	77°
VADL1Q	22.7	91°
ROVA1Q	28.5	93°
SDA1Q	48.2	106°
VANO1Q	18.4	335°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
ROVA1Q	DOGOD	VHF	left	323 (143)°	> 3000ft	1.0min timed	ICAO rules
ROVA1Q	EKVAD	VHF	left	241 (61)°	3000ft - 8500ft	1.0min timed	ICAO rules
SDA1Q	DOGOD	VHF	left	323 (143)°	> 3000ft	1.0min timed	ICAO rules
SDA1R	NENED	VHF	left	306 (126)°	5500ft - 7000ft	1.0min timed	ICAO rules

SIVN1Q	KIK	NDB	left	236 (56)°	> 3000ft	1.0min timed	ICAO rules
VADL1Q	DOGOD	VHF	left	323 (143)°	> 3000ft	1.0min timed	ICAO rules
VADL1Q	EKVAD	VHF	left	241 (61)°	3000ft - 8500ft	1.0min timed	ICAO rules
VANO1Q	KIK	NDB	left	236 (56)°	> 3000ft	1.0min timed	ICAO rules

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only