### Airport details

State	[Other]		
Country	International Waters		
Region			
Elevation	0ft (0m)		
Timezone	GMT +1		
Coordinates	56.64069, 3.32615		
Туре	helipad		
ICAO code	ENXT		
IATA code	n/a		
FAA code	n/a		

### Communication

No airport communication available for ENXT

#### Nearby beacons

code	identifier	dist	bearing	frequency
EKO	EKOFISK-L NDB	6.8	226.2°	375
UL	DME	32.3	314.5°	116.45
ULA	ULA NDB	32.3	314.2°	380

# Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

# To be used with X-Plane simulation only