

ESNX - Arvidsjaur

Airport details

State	Norrbottna län
Country	Sweden
Region	ES
Elevation	1245ft (379m)
Timezone	GMT +1
Coordinates	65.59028, 19.28194
Type	land
ICAO code	ESNX
IATA code	AJR
FAA code	n/a

Runway info

Runway 12 / 30	
length	2549m (8363ft)
bearing	108° / 288°
width	45m (148ft)
surface	asphalt
displacement threshold	60m (197ft) / 0m (0ft)
Runway 13 / 31	
length	610m (2001ft)
bearing	109° / 289°
width	30m (100ft)

Communication

Arvidsjaur AFIS	123.000
Arvidsjaur TWR	123.000
Arvidsjaur AFIS	123.000
Arvidsjaur TWR	123.000
Arvidsjaur AFIS	123.000
Arvidsjaur TWR	123.000
Arvidsjaur AFIS	123.000
Arvidsjaur TWR	123.000

Approach frequencies

ILS-cat-I	12	109.35	18.00mi
ILS-cat-I	30	111.5	18.00mi
3° GS	12	109.35	18.00mi
3° GS	30	111.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
AS	ARVIDSJOUR NDB	2.7	108.1°	358
AN	ARVIDSJOUR NDB	4.3	287.4°	381
DD	LYCKSELE NDB	61.7	213.5°	333

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only