

ETHF - Fritzlar - Fritzlar Ab

Airport details

State	Hesse
Country	Germany
Region	ED
Elevation	564ft (172m)
Timezone	GMT +1
Coordinates	51.11696, 9.28680
Type	land
ICAO code	ETHF
IATA code	FRZ
FAA code	n/a

Runway info

Runway 12 / 30	
length	1043m (3422ft)
bearing	109° / 289°
width	30m (98ft)
surface	asphalt

Communication

Fritzlar AB Fritzlar Tower	122.100
Fritzlar AB Fritzlar Tower	122.100
Fritzlar AB Fritzlar Tower	122.100
Fritzlar AB Fritzlar Tower	122.100
Fritzlar AB Fritzlar Radar	135.600
Fritzlar AB Fritzlar Radar	135.600
Fritzlar AB Fritzlar Radar	135.600
Fritzlar AB Fritzlar Radar	135.600

Nearby beacons

code	identifier	dist	bearing	frequency
FTZ	FRITZLAR NDB	5.2	104.2°	468
DKS	DME-ILS	18.8	21.2°	111.50
WRB	WARBURG VOR/DME	24.2	335.6°	113.70
FUL	FULDA VOR/DME	33.3	151.4°	112.10
PAD	DME-ILS	38.7	306.4°	108.50
PAD	PADERBORN-LIPPSTADT NDB	38.9	308°	354
GED	GEDERN VORTAC	42.3	183°	110.80
MTR	METRO VOR	53.1	207.5°	110

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only