

# FVHA - Harare - Robert Gabriel Mugabe Intl

---

## Airport details

State	Harare
Country	Zimbabwe
Region	FV
Elevation	4898ft (1493m)
Timezone	GMT +2
Coordinates	-17.93047, 31.08886
Type	land
ICAO code	FVHA
IATA code	HRE
FAA code	n/a

## Runway info

Runway 05 / 23	
length	4735m (15535ft)
bearing	46° / 226°
width	46m (150ft)
surface	asphalt
blast zone	97m (318ft) / 78m (256ft)

## Communication

Robert Gabriel Mugabe Intl ATIS	113.100
Robert Gabriel Mugabe Intl ATIS	113.100
Robert Gabriel Mugabe Intl ATIS	113.100
Robert Gabriel Mugabe Intl ATIS	113.100
Robert Gabriel Mugabe Intl GND	127.300
Robert Gabriel Mugabe Intl GND	127.300
Robert Gabriel Mugabe Intl GND	127.300
Robert Gabriel Mugabe Intl GND	127.300
Robert Gabriel Mugabe Intl TWR	118.100
Robert Gabriel Mugabe Intl TWR	118.100
Robert Gabriel Mugabe Intl TWR	118.100
Robert Gabriel Mugabe Intl TWR	118.100
Robert Gabriel Mugabe Intl APP	119.100
Robert Gabriel Mugabe Intl APP	119.100
Robert Gabriel Mugabe Intl APP	119.100
Robert Gabriel Mugabe Intl APP	119.100

## Nearby beacons

code	identifier	dist	bearing	frequency
------	------------	------	---------	-----------

SI	ROBERT GABRIEL MUGABE INTL NDB	1.7	219.1°	330
VHA	HARARE VOR/DME	2.1	51.8°	113.10
OL	ROBERT GABRIEL MUGABE INTL NDB	5.1	223.8°	346
CP	CHARLES PRINCE (HARARE) NDB	14.2	317.8°	414
BZ	BROMLEY (HARARE) NDB	16.4	118.6°	284
NZ	NORTON (HARARE) NDB	23.1	272.5°	373
KU	MAKUMBI (HARARE) NDB	26.2	22.6°	363

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only