

# HEAR - El Arish - El Arish Intl

---

## Airport details

State	North Sinai
Country	Egypt
Region	HE
Elevation	121ft (37m)
Timezone	GMT +2
Coordinates	31.07333, 33.83583
Type	land
ICAO code	HEAR
IATA code	AAC
FAA code	n/a

## Runway info

Runway 16 / 34	
length	3026m (9928ft)
bearing	154° / 334°
width	45m (148ft)
surface	asphalt
blast zone	54m (177ft) / 76m (249ft)

## Communication

El Arish Intl GND	121.900
El Arish Intl GND	121.900
El Arish Intl GND	121.900
El Arish Intl GND	121.900
El Arish Intl TWR	121.000
El Arish Intl TWR	121.000
El Arish Intl TWR	121.000
El Arish Intl TWR	121.000
El Arish Intl RADAR	125.000
El Arish Intl RADAR	123.725
El Arish Intl RADAR	125.000
El Arish Intl RADAR	123.725
El Arish Intl RADAR	123.725
El Arish Intl RADAR	125.000
El Arish Intl RADAR	123.725
El Arish Intl RADAR	125.000

## Nearby beacons

code	identifier	dist	bearing	frequency
------	------------	------	---------	-----------

ARH	EL ARISH VOR/DME	0.2	265.1°	113.60
BSA	BEER SHEBA VOR/DME	47.2	76.4°	114.30

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only