

HETR - El Tor

Airport details

State	South Sinai
Country	Egypt
Region	HE
Elevation	115ft (35m)
Timezone	GMT +2
Coordinates	28.21667, 33.63500
Type	land
ICAO code	HETR
IATA code	ELT
FAA code	n/a

Runway info

Runway 10 / 28	
length	2997m (9833ft)
bearing	103° / 283°
width	45m (148ft)
surface	asphalt
blast zone	64m (210ft) / 64m (210ft)

Communication

EL TOR GND	121.900
EL TOR GND	121.900
EL TOR GND	121.900
EL TOR GND	121.900
EL TOR TWR	121.300
EL TOR TWR	121.300
EL TOR TWR	121.300
EL TOR TWR	121.300

Nearby beacons

code	identifier	dist	bearing	frequency
SHM	SHARM EL SHEIKH VOR/DME	43.2	105.6°	114.20

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only