## Airport details

| State       |
|-------------|
| Country     |
| Region      |
| Elevation   |
| Timezone    |
| Coordinates |
| Туре        |
| ICAO code   |
| IATA code   |
| FAA code    |

Northern State Sudan HS 960ft (293m) GMT +3 21.80572, 31.52766 land HSSW WHF n/a

## Runway info

| Runway 06 / 24         |                             |
|------------------------|-----------------------------|
| length                 | 2057m (6749ft)              |
| bearing                | 63° / 243°                  |
| width                  | 46m (151ft)                 |
| surface                | dirt                        |
| displacement threshold | 33m (108ft) / 21m (69ft)    |
| blast zone             | 255m (837ft) / 255m (837ft) |
| Runway 01 / 19         |                             |
| length                 | 345m (1132ft)               |
| bearing                | 11° / 191°                  |
| width                  | 17m (56ft)                  |
| surface                | dirt                        |
| displacement threshold | 12m (39ft) / 13m (43ft)     |

## Communication

No airport communication available for HSSW

#### Nearby beacons

| code | identifier         | dist | bearing | frequency |
|------|--------------------|------|---------|-----------|
| SML  | ABU SIMBEL VOR/DME | 33.4 | 9.7°    | 113.50    |

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

# To be used with X-Plane simulation only