

I91 - Boonville

Airport details

State	Indiana
Country	United States of America
Region	
Elevation	377ft (115m)
Timezone	GMT -6
Coordinates	38.04245, -87.32008
Type	land
ICAO code	I91
IATA code	n/a
FAA code	I91

Runway info

Runway 09 / 27	
length	702m (2303ft)
bearing	96° / 276°
width	30m (100ft)
surface	grass
displacement threshold	91m (299ft) / 91m (299ft)

Communication

No airport communication available for I91

Nearby beacons

code	identifier	dist	bearing	frequency
EVV	VICCI (EVANSVILLE) NDB	7.6	304.8°	219
OWB	OWENSBORO VOR/DME	19.3	152.7°	108.60
PXV	POCKET CITY (EVANSVILLE) VORTAC	22	255.5°	113.30
CCT	CITY DME	39.7	175.1°	109.80
SAM	SAMSVILLE VOR/DME	44.8	300°	116.60
LWV	DME	45.6	338.6°	108.80
OLY	OLNEY NDB	57	308.4°	272
PLX	PALESTINE (ROBINSON) NDB	60.2	341.6°	391

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only