

II50 - Lewisville - Jack Oak

Airport details

State	Indiana
Country	United States of America
Region	
Elevation	790ft (241m)
Timezone	GMT -5
Coordinates	39.48461, -86.67699
Type	land
ICAO code	II50
IATA code	n/a
FAA code	II50

Runway info

Runway 18 / 36	
length	397m (1302ft)
bearing	179° / 359°
width	15m (50ft)
surface	grass

Communication

No airport communication available for II50

Nearby beacons

code	identifier	dist	bearing	frequency
OOM	HOOSIER (BLOOMINGTON) VORTAC	20.6	169.3°	110.20
VHP	BRICKYARD VORTAC	24.4	43.1°	116.30
CO	COLFA (INDIANAPOLIS) NDB	24.9	70.6°	232
TTH	TERRE HAUTE VORTAC	26.5	270.4°	115.30
FV	LAREZ (INDIANAPOLIS) NDB	28.6	57.8°	349
CFJ	CRAWFORDSVILLE NDB	31.7	334.3°	388
HU	YINNO (TERRE HAUTE) NDB	33.9	262.3°	245
UMP	METROPOLITAN (INDIANAPOLIS) NDB	39.7	54.1°	338
SHB	SHELBYVILLE VOR/DME	40.4	80.1°	112
BA	CLIFS (COLUMBUS) NDB	41	100.7°	410
PLX	PALESTINE (ROBINSON) NDB	53	243.9°	391
LA	EARLE (LAFAYETTE) NDB	59.1	338.2°	401
LWV	DME	60.8	232.3°	108.80
DN	JULIP (DANVILLE) NDB	62.3	313.3°	332
DNV	DANVILLE VORTAC	63.3	312.5°	111

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only