

# KCPK - Norfolk - Chesapeake Rgnl

---

## Airport details

State	Virginia
Country	United States of America
Region	K6
Elevation	20ft (6m)
Timezone	GMT -5
Coordinates	36.66416, -76.32436
Type	land
ICAO code	KCPK
IATA code	n/a
FAA code	CPK

## Runway info

Runway 5 / 23	
length	1678m (5505ft)
bearing	43° / 223°
width	30m (100ft)
surface	asphalt

## Communication

Chesapeake Rgnl AWOS 3	123.675
Chesapeake Rgnl AWOS 3	123.675
Chesapeake Rgnl AWOS 3	123.675
Chesapeake Rgnl AWOS 3	123.675
Chesapeake Rgnl CTAF/UNICOM	123.075
Chesapeake Rgnl CTAF/UNICOM	123.075
Chesapeake Rgnl CTAF/UNICOM	123.075
Chesapeake Rgnl CTAF/UNICOM	123.075
Chesapeake Rgnl NORFOLK APP/DEP	118.900
Chesapeake Rgnl NORFOLK APP/DEP	118.900
Chesapeake Rgnl NORFOLK APP/DEP	118.900
Chesapeake Rgnl NORFOLK APP/DEP	118.900

## Approach frequencies

ILS-cat-I	05	111.7	18.00mi
3° GS	05	111.7	18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
------	------------	------	---------	-----------

NFE	CHESAPEAKE TACAN	9.2	79.9°	108.25
OR	INGLE (NORFOLK) NDB	11.1	22.4°	329
ORF	NORFOLK VORTAC	14.9	28.5°	116.90
NGU	CHAMBERS (NORFOLK) TACAN	16.7	9.6°	113.95
NTU	OCEANA TACAN	16.8	60.8°	116.60
LLW	WOODVILLE (ELIZABETH CITY) NDB	24.1	176.2°	254
LFI	LANGLEY (HAMPTON) TACAN	25.3	355.2°	112.30
ECG	ELIZABETH CITY VOR/DME	25.4	159.9°	112.50
CVI	COFIELD VORTAC	31.6	241.9°	114.60
FKN	FRANKLIN VORTAC	33.2	274.1°	110.60
AKQ	WAKEFIELD NDB	37.7	295.2°	274
CCV	CAPE CHARLES VORTAC	43.9	25.5°	112.20
HCM	HARCUM VORTAC	50.6	333.7°	108.80
RBX	WRIGHT BROTHERS (MANTEO) VOR/DME	54	139.8°	111.60
MQI	MANTEO NDB	54.3	139.9°	370
HPW	HOPEWELL VORTAC	55	310°	112
RIC	RICHMOND VORTAC	69.3	310°	114.10

## Departure and arrival routes

Transition altitude	18000ft
Transition level	18000ft

<b>STAR starting points</b>	<b>distance</b>	<b>inbound direction</b>
ALL		
DRONE2	18.5	69°
TERKS2	152.2	114°

## Holding patterns

<b>STAR name</b>	<b>hold at</b>	<b>type</b>	<b>turn</b>	<b>heading*</b>	<b>altitude</b>	<b>leg</b>	<b>speed limit</b>
DRONE2	DRONE	VHF	right	233 (53)°		1.0min timed	ICAO rules

\*) magnetic outbound (inbound) holding course

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only