

KJHW - Jamestown - Chautauqua Co Jamestown

Airport details

State	New York
Country	United States of America
Region	K6
Elevation	1723ft (525m)
Timezone	GMT -5
Coordinates	42.15339, -79.25803
Type	land
ICAO code	KJHW
IATA code	JHW
FAA code	JHW

Runway info

Runway 7 / 25	
length	1617m (5305ft)
bearing	66° / 246°
width	30m (98ft)
surface	asphalt
Runway 13 / 31	
length	1373m (4505ft)
bearing	112° / 292°
width	30m (98ft)
surface	asphalt

Communication

CHAUTAUQUA CO JAMESTOWN AWOS 3	118.425
CHAUTAUQUA CO JAMESTOWN AWOS 3	118.425
CHAUTAUQUA CO JAMESTOWN AWOS 3	118.425
CHAUTAUQUA CO JAMESTOWN AWOS 3	118.425
CHAUTAUQUA CO JAMESTOWN CTAF/UNICOM	122.700
CHAUTAUQUA CO JAMESTOWN CTAF/UNICOM	122.700
CHAUTAUQUA CO JAMESTOWN CTAF/UNICOM	122.700
CHAUTAUQUA CO JAMESTOWN CTAF/UNICOM	122.700
CHAUTAUQUA CO JAMESTOWN CLNC DEL	126.200

CHAUTAUQUA CO JAMESTOWN CLNC 126.200
DEL
CHAUTAUQUA CO JAMESTOWN CLNC 126.200
DEL
CHAUTAUQUA CO JAMESTOWN CLNC 126.200
DEL
CHAUTAUQUA CO JAMESTOWN GND 121.800
CHAUTAUQUA CO JAMESTOWN GND 121.800
CHAUTAUQUA CO JAMESTOWN GND 121.800
CHAUTAUQUA CO JAMESTOWN GND 121.800
CHAUTAUQUA CO JAMESTOWN TWR 120.200
CHAUTAUQUA CO JAMESTOWN TWR 120.200
CHAUTAUQUA CO JAMESTOWN TWR 120.200
CHAUTAUQUA CO JAMESTOWN TWR 120.200
CHAUTAUQUA CO JAMESTOWN ERIE 126.050
APP/DEP
CHAUTAUQUA CO JAMESTOWN ERIE 126.050
APP/DEP
CHAUTAUQUA CO JAMESTOWN ERIE 126.050
APP/DEP
CHAUTAUQUA CO JAMESTOWN ERIE 126.050
APP/DEP

Approach frequencies

ILS-cat-I	25	109.7	18.00mi
3° GS	25	109.7	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
JHW	JAMESTOWN VOR/DME	6.4	75.5°	114.70
DKK	DME	20.2	357.2°	116.20
TDT	DME	27.3	199.8°	117.60
BFD	DME	36	119.8°	116.60
GB	PLAZZ (BUFFALO) NDB	47.4	31.5°	204
FKL	FRANKLIN VOR	50.6	219.9°	109.60
BUF	BUFFALO VOR/DME	53.8	38.2°	116.40
BU	KLUMP (BUFFALO) NDB	57.5	35.6°	231
IAG	NIAGARA FALLS TACAN	59	17.2°	111
SN	ST CATHARINES NDB	59.6	0.1°	408
IA	KATHI (NIAGRA FALLS) NDB	60.3	23.7°	329
ZHM	BINBROOK (HAMILTON) NDB	64	331.6°	266
HM	HAMILTON NDB	66.8	322.2°	221

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only