

# KJVY - Jeffersonville - Clark Regional

---

## Airport details

State	Indiana
Country	United States of America
Region	K5
Elevation	474ft (144m)
Timezone	GMT -5
Coordinates	38.36542, -85.73820
Type	land
ICAO code	KJVY
IATA code	n/a
FAA code	JVY

## Runway info

Runway 18 / 36	
length	1680m (5512ft)
bearing	180° / 360°
width	30m (100ft)
surface	asphalt
Runway 14 / 32	
length	1189m (3901ft)
bearing	131° / 311°
width	23m (75ft)
surface	asphalt

## Communication

Clark Regional AWOS 3	118.575
Clark Regional AWOS 3	118.575
Clark Regional AWOS 3	118.575
Clark Regional AWOS 3	118.575
Clark Regional CTAF/UNICOM	122.700
Clark Regional CTAF/UNICOM	122.700
Clark Regional CTAF/UNICOM	122.700
Clark Regional CTAF/UNICOM	122.700

## Approach frequencies

ILS-cat-I	18	111.7	18.00mi
3° GS	18	111.7	18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
JV	CATCH (JEFFERSONVILLE) NDB	6.5	0.5°	331
BQM	(LOUISVILLE) DME	8.8	151.4°	112.20
LK	LAANG (LOUISVILLE) NDB	14.1	154.5°	414
IIU	LOUISVILLE VORTAC	17.4	148.4°	114.80
GVR	(MADISON) DME	26.7	34.2°	114.65
FTK	FORT KNOX VOR/DME	29.6	207°	109.60
MYS	MYSTIC VOR	37	227°	108.20
FFT	FRANKFORT VOR	40.6	102.4°	109.40
EWO	NEW HOPE VOR/DME	44.1	175.1°	110.80
BA	CLIFS (COLUMBUS) NDB	57.5	355.1°	410
OOM	HOOSIER (BLOOMINGTON) VORTAC	62.1	311.6°	110.20
HLB	BATESVILLE NDB	63	26°	254
DVK	GOODALL (DANVILLE) NDB	66.1	129°	311

## Departure and arrival routes

Transition altitude	18000ft
Transition level	18000ft

STAR starting points	distance	inbound direction
ALL		
CHERI4	37.4	80°
RDSTN6	20.3	267°
DARBY7	56.5	312°

## Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
CHERI4	CHERI	VHF	left	279 (99)°		1.0min timed	ICAO rules
DARBY7	DARBY	VHF	right	132 (312)°		1.0min timed	ICAO rules
RDSTN6	CVG	NDB	right	59 (239)°		DME 4.0mi	ICAO rules
RDSTN6	NERVE	VHF	left	41 (221)°		1.0min timed	ICAO rules
RDSTN6	ZOPOM	VHF	left	36 (216)°		1.0min timed	ICAO rules

\*) magnetic outbound (inbound) holding course

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only