

KMLU - Monroe - Monroe Rgnl

Airport details

State	Louisiana
Country	United States of America
Region	K4
Elevation	79ft (24m)
Timezone	GMT -6
Coordinates	32.51086, -92.03767
Type	land
ICAO code	KMLU
IATA code	MLU
FAA code	MLU

Runway info

Runway 4 / 22	
length	2285m (7497ft)
bearing	50° / 230°
width	46m (150ft)
surface	asphalt
blast zone	61m (200ft) / 62m (203ft)
Runway 14 / 32	
length	1522m (4993ft)
bearing	135° / 315°
width	46m (150ft)
surface	asphalt

Communication

Monroe Rgnl ATIS	125.050
Monroe Rgnl ATIS	125.050
Monroe Rgnl ATIS	125.050
Monroe Rgnl ATIS	125.050
Monroe Rgnl UNICOM	122.950
Monroe Rgnl CTAF	118.900
Monroe Rgnl UNICOM	122.950
Monroe Rgnl UNICOM	122.950
Monroe Rgnl CTAF	118.900
Monroe Rgnl CTAF	118.900
Monroe Rgnl UNICOM	122.950
Monroe Rgnl CTAF	118.900
Monroe Rgnl CLNC DEL	121.650
Monroe Rgnl CLNC DEL	121.650
Monroe Rgnl CLNC DEL	121.650
Monroe Rgnl CLNC DEL	121.650

Monroe Rgnl MONROE GROUND	121.900
Monroe Rgnl MONROE GROUND	121.900
Monroe Rgnl MONROE GROUND	121.900
Monroe Rgnl MONROE GROUND	121.900
Monroe Rgnl MONROE TOWER	118.900
Monroe Rgnl MONROE TOWER	118.900
Monroe Rgnl MONROE TOWER	118.900
Monroe Rgnl MONROE TOWER	118.900
Monroe Rgnl FT. WORTH APP/DEP	126.325
Monroe Rgnl MONROE APP/DEP	118.150
Monroe Rgnl FT. WORTH APP/DEP	126.325
Monroe Rgnl MONROE APP/DEP	118.150
Monroe Rgnl MONROE APP/DEP	118.150
Monroe Rgnl MONROE APP/DEP	118.150
Monroe Rgnl FT. WORTH APP/DEP	126.325
Monroe Rgnl FT. WORTH APP/DEP	126.325

Approach frequencies

ILS-cat-I	04	109.5	18.00mi
ILS-cat-I	22	109.5	18.00mi
3° GS	04	109.5	18.00mi
3° GS	22	109.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
MLU	MONROE VORTAC	0.3	15.3°	117.20
ML	SABAR (MONROE) NDB	4.7	229.5°	392
BQP	BASTROP NDB	16.5	32.3°	329
FWV	TRUXNO (FARMERVILLE) NDB	24.2	312.4°	379
ROQ	RUSTON NDB	28.4	280°	368
SWB	SAWMILL (WINNFIELD) VOR/DME	45.8	229.9°	113.75
ELD	EL DORADO VOR/DME	57.2	316.5°	115.50
EL	LADOS (EL DORADO) NDB	58.1	318.3°	418
HAH	NATCHEZ-ADAMS COUNTY NDB	62.1	137.7°	388
HEZ	NATCHEZ VOR/DME	65.4	140.4°	110

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only