

KMWH - Moses Lake - Grant Co Intl

Airport details

State	Washington
Country	United States of America
Region	K1
Elevation	1185ft (361m)
Timezone	GMT -8
Coordinates	47.20858, -119.31914
Type	land
ICAO code	KMWH
IATA code	MWH
FAA code	MWH

Runway info

Runway 14L / 32R	
length	4116m (13504ft)
bearing	155° / 335°
width	61m (200ft)
surface	asphalt
blast zone	255m (837ft) / 255m (837ft)
Runway 4 / 22	
length	3043m (9984ft)
bearing	64° / 244°
width	30m (100ft)
surface	asphalt
blast zone	255m (837ft) / 255m (837ft)
Runway 9 / 27	
length	1064m (3491ft)
bearing	103° / 283°
width	27m (90ft)
surface	concrete
Runway 18 / 36	
length	1019m (3343ft)
bearing	206° / 26°
width	23m (75ft)
surface	asphalt
blast zone	28m (92ft) / 0m (0ft)
Runway 14R / 32L	
length	895m (2936ft)
bearing	155° / 335°
width	23m (75ft)
surface	concrete

Communication

Grant Co Intl ATIS	119.050
Grant Co Intl ATIS	119.050
Grant Co Intl ATIS	119.050
Grant Co Intl ATIS	119.050
Grant Co Intl UNICOM	122.950
Grant Co Intl CTAF	118.250
Grant Co Intl UNICOM	122.950
Grant Co Intl CTAF	118.250
Grant Co Intl CTAF	118.250
Grant Co Intl UNICOM	122.950
Grant Co Intl UNICOM	122.950
Grant Co Intl CTAF	118.250
Grant Co Intl GND	121.900
Grant Co Intl GND	121.900
Grant Co Intl GND	121.900
Grant Co Intl GND	121.900
Grant Co Intl TWR	118.250
Grant Co Intl TWR	128.000
Grant Co Intl TWR	118.250
Grant Co Intl TWR	128.000
Grant Co Intl TWR	128.000
Grant Co Intl TWR	118.250
Grant Co Intl TWR	128.000
Grant Co Intl TWR	118.250
Grant Co Intl APP/DEP	126.400
Grant Co Intl APP/DEP	134.350
Grant Co Intl APP/DEP	126.400
Grant Co Intl APP/DEP	134.350
Grant Co Intl APP/DEP	126.400
Grant Co Intl APP/DEP	134.350
Grant Co Intl APP/DEP	126.400
Grant Co Intl APP/DEP	134.350

Approach frequencies

ILS-cat-I	32R	109.5	18.00mi
3° GS	32R	109.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
MWH	MOSES LAKE VOR/DME	0.1	45.4°	115
MW	PELLY (MOSES LAKE) NDB	5.8	154.3°	408
EPH	EPHRATA VORTAC	11	328.2°	112.60
EAT	WENATCHEE VOR/DME	38	282°	111
PSC	PASCO VOR/DME	56.9	167.8°	109.80

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only