

KSFQ - Suffolk - Suffolk Executive

Airport details

State	Virginia
Country	United States of America
Region	K6
Elevation	70ft (21m)
Timezone	GMT -5
Coordinates	36.68289, -76.59962
Type	land
ICAO code	KSFQ
IATA code	n/a
FAA code	SFQ

Runway info

Runway 4 / 22	
length	1528m (5013ft)
bearing	36° / 216°
width	30m (98ft)
surface	asphalt
Runway 7 / 25	
length	1433m (4701ft)
bearing	68° / 248°
width	30m (98ft)
surface	asphalt
displacement threshold	292m (958ft) / 0m (0ft)
blast zone	57m (187ft) / 81m (266ft)

Communication

Suffolk Executive AWOS 3	119.375
Suffolk Executive AWOS 3	119.375
Suffolk Executive AWOS 3	119.375
Suffolk Executive AWOS 3	119.375
Suffolk Executive CTAF/UNICOM	122.700
Suffolk Executive CTAF/UNICOM	122.700
Suffolk Executive CTAF/UNICOM	122.700
Suffolk Executive CTAF/UNICOM	122.700
Suffolk Executive NORFOLK APP/DEP	127.900
Suffolk Executive NORFOLK APP/DEP	127.900
Suffolk Executive NORFOLK APP/DEP	127.900
Suffolk Executive NORFOLK APP/DEP	127.900

Approach frequencies

LOC 04 109.95 18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
OR	INGLE (NORFOLK) NDB	19.2	65.6°	329
FKN	FRANKLIN VORTAC	19.9	274.3°	110.60
NGU	CHAMBERS (NORFOLK) TACAN	21.8	51.4°	113.95
NFE	CHESAPEAKE TACAN	22.2	88.1°	108.25
CVI	COFIELD VORTAC	22.7	221.2°	114.60
ORF	NORFOLK VORTAC	22.9	62.3°	116.90
AKQ	WAKEFIELD NDB	26.3	306.7°	274
LFI	LANGLEY (HAMPTON) TACAN	26.7	30.8°	112.30
NTU	OCEANA TACAN	28.3	75.8°	116.60
LLW	WOODVILLE (ELIZABETH CITY) NDB	29.1	144.3°	254
ECG	ELIZABETH CITY VOR/DME	32.7	135°	112.50
HPW	HOPEWELL VORTAC	46	321.3°	112
HCM	HARCUM VORTAC	46.3	351.6°	108.80
CCV	CAPE CHARLES VORTAC	49.2	42.1°	112.20
RIC	RICHMOND VORTAC	60.1	318.6°	114.10
RBX	WRIGHT BROTHERS (MANTEO) VOR/DME	63.2	130.1°	111.60
MQI	MANTEO NDB	63.5	130.3°	370
AQE	ALWOOD (GREENVILLE) NDB	69.5	218.3°	230

Departure and arrival routes

Transition altitude 18000ft
Transition level 18000ft

STAR starting points	distance	inbound direction
ALL		
TERKS2	140.3	116°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only