

KTUL - Tulsa - Tulsa Intl

Airport details

State	Oklahoma
Country	United States of America
Region	K4
Elevation	675ft (206m)
Timezone	GMT -6
Coordinates	36.19839, -95.88811
Type	land
ICAO code	KTUL
IATA code	TUL
FAA code	TUL

Runway info

Runway 18L / 36R	
length	3055m (10023ft)
bearing	184° / 4°
width	46m (150ft)
surface	concrete
blast zone	62m (203ft) / 62m (203ft)
Runway 8 / 26	
length	2244m (7362ft)
bearing	90° / 270°
width	46m (151ft)
surface	concrete
blast zone	51m (167ft) / 0m (0ft)
Runway 18R / 36L	
length	1864m (6115ft)
bearing	184° / 4°
width	46m (151ft)
surface	asphalt

Communication

Tulsa Intl ATIS	124.900
Tulsa Intl ATIS	124.900
Tulsa Intl ATIS	124.900
Tulsa Intl ATIS	124.900
Tulsa Intl UNICOM	122.950
Tulsa Intl UNICOM	122.950
Tulsa Intl UNICOM	122.950
Tulsa Intl UNICOM	122.950
Tulsa Intl CLNC DEL	134.050
Tulsa Intl CLNC DEL	134.050

Tulsa Intl CLNC DEL	134.050
Tulsa Intl CLNC DEL	134.050
Tulsa Intl GND	121.900
Tulsa Intl GND	121.900
Tulsa Intl GND	121.900
Tulsa Intl GND	121.900
Tulsa Intl TWR	118.700
Tulsa Intl TWR	118.700
Tulsa Intl TWR	118.700
Tulsa Intl TWR	118.700
Tulsa Intl APP/DEP	119.100
Tulsa Intl APP/DEP	119.100
Tulsa Intl APP/DEP	119.100
Tulsa Intl APP/DEP	119.100

Approach frequencies

ILS-cat-II	36R	110.3	18.00mi
ILS-cat-I	18L	109.7	18.00mi
ILS-cat-I	18R	111.1	18.00mi
3° GS	36R	110.3	18.00mi
2.7° GS	18L	109.7	18.00mi
2.7° GS	18R	111.1	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
TUL	TULSA VORTAC	4.8	91.2°	114.40
TU	OILLR (TULSA) NDB	6	180.3°	338
GNP	(TULSA) DME	17.1	196.1°	110.60
OK	PRESO (OKMULGEE) NDB	26.7	187.7°	388
OKM	OKMULGEE VOR/DME	30.3	177.4°	114.90
BVO	BARTLESVILLE VOR/DME	38.7	348.4°	117.90
BV	DEWIE (BARTLESVILLE) NDB	38.9	348.8°	201
HET	HENRYETTA NDB	48	189°	267
OSW	OSWEGO VOR/DME	66.3	35.5°	117.60
SRE	SEMINOLE NDB	67.5	220.3°	278

Departure and arrival routes

Transition altitude	18000ft
Transition level	18000ft

SID end points	distance	outbound direction
RW08		
TUL9	12.1	269°
RW18 (ALL)		

RW26	TUL9	12.1	269°
	TUL9	12.1	269°
RW36 (ALL)	TUL9	12.1	269°

STAR starting points		distance	inbound direction
RW08			
	VINTA3	42.4	235°
RW18 (ALL)			
	VINTA3	42.4	235°
RW26			
	VINTA3	42.4	235°
RW36 (ALL)			
	VINTA3	42.4	235°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only