

LKLT - Letňany - Letnany

Airport details

State	Prague
Country	Czechia
Region	LK
Elevation	912ft (278m)
Timezone	GMT +1
Coordinates	50.12860, 14.52352
Type	land
ICAO code	LKLT
IATA code	n/a
FAA code	n/a

Runway info

Runway 05L / 23R	
length	861m (2825ft)
bearing	61° / 241°
width	23m (75ft)
surface	grass
Runway 05R / 23L	
length	801m (2628ft)
bearing	63° / 243°
width	25m (82ft)
surface	grass

Communication

Letnany Letnany INFO	120.325
Letnany Letnany INFO	120.325
Letnany Letnany INFO	120.325
Letnany Letnany INFO	120.325

Nearby beacons

code	identifier	dist	bearing	frequency
K	KBELY NDB	1.7	88.6°	438
KD	KBELY NDB	4.5	78°	300
V	MASLOVICE (VODOCHODY) NDB	7.9	301.6°	416
L	LIBOC (PRAGUE) NDB	9.1	267.9°	372
OKL	PRAGUE VOR/DME	10.1	262.7°	112.60
NER	NERATOVICE VOR/DME	14.7	22.3°	112.25
PSK	DME	27.9	234.8°	117.60
VLM	VLASIM VOR/DME	33	127.9°	114.30

F	CASLAV NDB	33.6	101.5°	715
C	CASLAV NDB	36	103°	715
CF	CASLAV NDB	37.5	103.8°	345
VOZ	VOZICE VOR/DME	38.3	149.5°	116.95
HDO	HERMSDORF VOR/DME	48.3	349°	108.65
OKX	FRYDLANT VOR/DME	50.3	33.2°	114.85
DRN	DRESDEN VOR/DME	63.8	313.8°	114.35

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only