

LTAL - Kastamonu

Airport details

State	Kastamonu Province
Country	Turkey
Region	LT
Elevation	3521ft (1073m)
Timezone	GMT +3
Coordinates	41.31694, 33.79611
Type	land
ICAO code	LTAL
IATA code	KFS
FAA code	n/a

Runway info

Runway 18 / 36	
length	2252m (7388ft)
bearing	189° / 9°
width	45m (148ft)
surface	asphalt
blast zone	80m (262ft) / 80m (262ft)

Communication

Kastamonu GND	121.900
Kastamonu GND	121.900
Kastamonu GND	121.900
Kastamonu GND	121.900
Kastamonu TWR	118.400
Kastamonu TWR	118.400
Kastamonu TWR	118.400
Kastamonu TWR	118.400

Approach frequencies

ILS-cat-I	18	108.5	18.00mi
3° GS	18	108.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
KTM	KASTAMONU NDB	0.7	203.9°	461
KST	KASTAMONU NDB	2	6.4°	359
INB	INEBOLU VOR/DME	38.3	351.9°	113.30

Departure and arrival routes

Transition altitude 12000ft

SID end points	distance	outbound direction
-----------------------	-----------------	---------------------------

RW18

IBUR1E	26.2	235°
GIRN1E	30.3	241°
OSRI1C, OSRI1D	18.5	267°
BAVB1E	29.2	352°
INB1C, INB1D	38.3	352°

RW36

IBUR1F	26.2	235°
GIRN1F	30.3	241°
OSRI1A, OSRI1B	18.5	267°
INB1A	38.3	352°
BAVB1F	29.2	352°

STAR starting points

distance

inbound direction

ALL

ORMA1K	18.5	87°
OSRI1K	14.5	88°
INB1K	38.3	172°

RW18

IBUR1H, IBUR1G	26.2	55°
GIRN1H, GIRN1G	30.3	61°
BAVB1H, BAVB1G	29.2	172°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
BAVB1G	ROXIR	VHF	left	1 (181)°	> 10000ft	1.0min timed	ICAO rules
BAVB1H	ROXIR	VHF	left	1 (181)°	> 10000ft	1.0min timed	ICAO rules
GIRN1G	REBRU	VHF	left	271 (91)°	> 8500ft	1.0min timed	ICAO rules
GIRN1H	REBRU	VHF	left	271 (91)°	> 8500ft	1.0min timed	ICAO rules
IBUR1G	REBRU	VHF	left	271 (91)°	> 8500ft	1.0min timed	ICAO rules
IBUR1H	REBRU	VHF	left	271 (91)°	> 8500ft	1.0min timed	ICAO rules
INB1K	KST	NDB	left	216 (36)°	> 9500ft	1.0min timed	230
ORMA1K	KST	NDB	left	216 (36)°	> 9500ft	1.0min timed	230
OSRI1K	KST	NDB	left	216 (36)°	> 9500ft	1.0min timed	230

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only