

MKJS - Montego Bay - Sangster Intl

Airport details

State	Saint James
Country	Jamaica
Region	MK
Elevation	2ft (1m)
Timezone	GMT -5
Coordinates	18.50367, -77.91338
Type	land
ICAO code	MKJS
IATA code	MBJ
FAA code	n/a

Runway info

Runway 07 / 25	
length	2661m (8730ft)
bearing	67° / 247°
width	49m (161ft)
surface	asphalt
displacement threshold	67m (220ft) / 171m (561ft)
blast zone	53m (174ft) / 61m (200ft)

Communication

Sangster Intl MKJS ATIS	127.900
Sangster Intl MKJS ATIS	127.900
Sangster Intl MKJS ATIS	127.900
Sangster Intl MKJS ATIS	127.900
Sangster Intl SANGSTER GND	121.700
Sangster Intl SANGSTER GND	121.700
Sangster Intl SANGSTER GND	121.700
Sangster Intl SANGSTER GND	121.700
Sangster Intl SANGSTER TWR	120.800
Sangster Intl SANGSTER TWR	120.800
Sangster Intl SANGSTER TWR	120.800
Sangster Intl SANGSTER TWR	120.800
Sangster Intl SANGSTER APP	120.800
Sangster Intl SANGSTER APP	120.800
Sangster Intl SANGSTER APP	120.800
Sangster Intl SANGSTER APP	120.800

Approach frequencies

ILS-cat-I	07	109.5	18.00mi
3° GS	07	109.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
SIA	SANGSTER VOR/DME	0.6	256.2°	115.70

Departure and arrival routes

Transition altitude	17000ft
Transition level	18000ft

SID end points

	distance	outbound direction
--	----------	--------------------

RW07

TILUP1, ELUTU4	39.8	18°
IMADI1	45.2	54°
LIBEX2	32.5	102°
KEMBO3	36.1	117°
KESPA2	41.9	129°
BOSOM7	39.5	191°
PETSI2	39.9	283°
NUBOX2	40.0	301°
ADSEL2	40.0	311°

RW25

TILUP1	39.8	18°
IMADI1	45.2	54°
LIBEX2	32.5	102°
KEMBO3	36.1	117°
KESPA2	41.9	129°
BOSOM7	39.5	191°
PETSI2	39.9	283°
NUBOX2	40.0	301°
ADSEL2	40.0	311°

STAR starting points

RW07

	distance	inbound direction
LENAR5	11.6	65°
OMAXI5	11.6	67°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
LENAR5	LENAR	VHF	left	250 (70)°	3000ft - 60000ft	DME 6.0mi	ICAO rules

OMAXI5	OMAXI	VHF	left	252 (72)°	3000ft - 60000ft	DME 6.0mi	ICAO rules
--------	-------	-----	------	-----------	---------------------	--------------	------------

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only