

MMCM - Chetumal - Chetumal Intl

Airport details

| | |
|-------------|---------------------|
| State | Quintana Roo |
| Country | Mexico |
| Region | MM |
| Elevation | 39ft (12m) |
| Timezone | GMT -5 |
| Coordinates | 18.50569, -88.32626 |
| Type | land |
| ICAO code | MMCM |
| IATA code | CTM |
| FAA code | n/a |

Runway info

| | |
|------------------------|------------------------------|
| Runway 10 / 28 | |
| length | 2697m (8848ft) |
| bearing | 107° / 287° |
| width | 47m (153ft) |
| surface | asphalt |
| displacement threshold | 493m (1617ft) / 263m (863ft) |
| blast zone | 60m (197ft) / 0m (0ft) |

Communication

| | |
|-------------------|---------|
| Chetumal Intl TWR | 118.800 |
| Chetumal Intl TWR | 118.800 |
| Chetumal Intl TWR | 118.800 |
| Chetumal Intl TWR | 118.800 |

Nearby beacons

| code | identifier | dist | bearing | frequency |
|------|------------------|------|---------|-----------|
| CTM | CHETUMAL VOR/DME | 0.4 | 295.9° | 116.30 |
| BZE | BELIZE VOR/DME | 58 | 179.2° | 114.30 |

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only