

# MMQT - Querétaro - Queretaro Intercontinental

---

## Airport details

State	Querétaro
Country	Mexico
Region	MM
Elevation	6294ft (1918m)
Timezone	GMT -6
Coordinates	20.62255, -100.19597
Type	land
ICAO code	MMQT
IATA code	QRO
FAA code	n/a

## Runway info

Runway 09 / 27	
length	3496m (11470ft)
bearing	100° / 280°
width	46m (151ft)
surface	concrete

## Communication

Queretaro Intercontinental TWR	118.950
Queretaro Intercontinental TWR	118.950
Queretaro Intercontinental TWR	118.950
Queretaro Intercontinental TWR	118.950

## Nearby beacons

code	identifier	dist	bearing	frequency
QET	QUERETARO VOR/DME	0.3	155.3°	113
PTJ	PASTEJE VOR/DME	62.8	157.8°	114.50
MLM	MORELIA VOR/DME	66.5	227.2°	114.60

## Departure and arrival routes

Transition altitude	18500ft
Transition level	19500ft

SID end points	distance	outbound direction
RW09		
OTRU1A	24.8	22°
ROGDI1	24.9	45°

	TIKEB1	24.2	127°
	DAVUL1	25.4	158°
	XUKV1A	25.4	186°
	DUPU1A	24.7	336°
RW27			
	OTRU1B	24.8	22°
	XUKV1B	25.4	186°
	XOSAS1	25.1	227°
	URNAT1	24.7	286°
	ONBIK1	24.7	301°
	PIGVU1	24.7	313°
	DUPU1B	24.7	336°

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only