

MS37 - Benoit - West Bolivar Flying Service

Airport details

State	Mississippi
Country	United States of America
Region	
Elevation	136ft (41m)
Timezone	GMT -6
Coordinates	33.66033, -90.99100
Type	land
ICAO code	MS37
IATA code	n/a
FAA code	MS37

Runway info

Runway 18 / 36	
length	1559m (5115ft)
bearing	176° / 356°
width	27m (90ft)
surface	grass

Communication

No airport communication available for MS37

Nearby beacons

code	identifier	dist	bearing	frequency
GLH	GREENVILLE VOR/DME	8.2	176.6°	114.25
MTQ	METCALF (GREENVILLE) NDB	14.1	177.8°	359
MON	MONTICELLO VOR/DME	36.7	262.2°	111.60
SQS	SIDON VORTAC	37.6	105.3°	114.70
GW	TEOCK NDB	45.5	94.3°	349
UJM	MARVELL (HELENA) VOR/DME	57.1	19°	109.60
PBF	PINE BLUFF VOR/DME	58.4	302°	116
TT	STUTT (STUTTGART) NDB	58.6	325°	338
BQP	BASTROP NDB	70.4	224.5°	329

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only