

MZTH - Orange Walk Town - Orange Walk

Airport details

State	Orange Walk
Country	Belize
Region	
Elevation	110ft (34m)
Timezone	GMT -6
Coordinates	18.04749, -88.58719
Type	land
ICAO code	MZTH
IATA code	ORZ
FAA code	n/a

Runway info

Runway 10 / 28	
length	693m (2274ft)
bearing	101° / 281°
width	10m (33ft)
surface	asphalt

Communication

No airport communication available for MZTH

Nearby beacons

code	identifier	dist	bearing	frequency
CTM	CHETUMAL VOR/DME	31.2	28.7°	116.30
BZE	BELIZE VOR/DME	34.2	151.7°	114.30

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only