

OR94 - Brownsville - Showa

Airport details

State	Oregon
Country	United States of America
Region	
Elevation	296ft (90m)
Timezone	GMT -8
Coordinates	44.38905, -123.02998
Type	land
ICAO code	OR94
IATA code	n/a
FAA code	OR94

Runway info

Runway 01 / 19	
length	557m (1827ft)
bearing	10° / 190°
width	8m (26ft)
surface	grass

Communication

No airport communication available for OR94

Nearby beacons

code	identifier	dist	bearing	frequency
CVO	CORVALLIS VOR/DME	13.1	292.7°	115.40
LWG	LEWISBURG (CORVALLIS) NDB	16.9	313°	225
EUG	EUGENE VORTAC	18.1	215.7°	112.90
SL	TURN0 (SALEM) NDB	27.7	9.7°	266
UBG	NEWBERG VOR/DME	57.9	3°	117.40

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only