

RJAW - Iwo Jima

Airport details

State	Tōkyō Prefecture
Country	Japan
Region	RJ
Elevation	388ft (118m)
Timezone	GMT +9
Coordinates	24.78417, 141.32278
Type	land
ICAO code	RJAW
IATA code	IWO
FAA code	n/a

Runway info

Runway 07 / 25	
length	2647m (8684ft)
bearing	70° / 250°
width	60m (197ft)
surface	asphalt
blast zone	171m (561ft) / 171m (561ft)

Communication

Iwo Jima TWR	126.200
Iwo Jima TWR	126.200
Iwo Jima TWR	126.200
Iwo Jima TWR	126.200

Nearby beacons

code	identifier	dist	bearing	frequency
IJT	IWOTO TACAN	0.3	274.5°	109.80
OX	IWOTO NDB	1	232.6°	360

Departure and arrival routes

Transition altitude	14000ft
Transition level	14000ft

SID end points		distance	outbound direction
RW07			
	CHD2	80.7	330°
RW25			

CHD2

80.7

330°

STAR starting points

RW07

CHD

distance

15.2

inbound direction

149°

RW25

CHD

15.2

149°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only