

RJOT - Takamatsu

Airport details

State	Kagawa Prefecture
Country	Japan
Region	RJ
Elevation	605ft (184m)
Timezone	GMT +9
Coordinates	34.21596, 134.01645
Type	land
ICAO code	RJOT
IATA code	TAK
FAA code	n/a

Runway info

Runway 08 / 26	
length	2497m (8192ft)
bearing	76° / 256°
width	60m (197ft)
surface	asphalt
blast zone	60m (197ft) / 60m (197ft)

Communication

Takamatsu ATIS	127.450
Takamatsu ATIS	127.450
Takamatsu ATIS	127.450
Takamatsu ATIS	127.450
Takamatsu TWR	126.200
Takamatsu TWR	118.300
Takamatsu TWR	126.200
Takamatsu TWR	118.300
Takamatsu TWR	118.300
Takamatsu TWR	126.200
Takamatsu TWR	135.900
Takamatsu TWR	126.200
Takamatsu TWR	118.300
Takamatsu TWR	135.900
Takamatsu TWR	135.900
Takamatsu TWR	135.900
Takamatsu TCA	119.025
Takamatsu APP	120.400
Takamatsu APP	121.200
Takamatsu APP	120.400
Takamatsu TCA	119.025

Takamatsu APP	121.200
Takamatsu TCA	119.025
Takamatsu APP	121.200
Takamatsu APP	120.400
Takamatsu TCA	119.025
Takamatsu APP	121.200
Takamatsu APP	120.400
Takamatsu DEP	121.200
Takamatsu DEP	120.400
Takamatsu DEP	121.200
Takamatsu DEP	120.400
Takamatsu DEP	120.400
Takamatsu DEP	121.200
Takamatsu DEP	120.400
Takamatsu DEP	121.200

Approach frequencies

ILS-cat-I	26	109.7	18.00mi
3° GS	26	109.7	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
KTE	KAGAWA (TAKAMATSU) VOR/DME	0.3	119.3°	108.40
TZT	TAKAMATSU TACAN	7.3	330.4°	117.50
STD	DME	21.9	41°	114.40
OKT	OKAYAMA TACAN	27.3	359.8°	115.90
TS	TOKUSHIMA NDB	29.7	98.4°	332
TSC	TOKUSHIMA VORTAC	29.8	98.2°	114.90
KJT	KOMATSUSHIMA TACAN	32.8	109.1°	113.55
OYE	KIBI VOR/DME	33.3	341.2°	111
AJD	DME	34.7	85.5°	115.60
KRE	KOCHI VOR/DME	43.8	206.5°	113.70

Departure and arrival routes

Transition altitude	14000ft
Transition level	14000ft

SID end points	distance	outbound direction
RW08		
SAYOH2	93.9	42°
OLIVE2	149.6	78°
WASYU3	34.9	292°
TAROH3	91.1	325°
KTE3N	33.3	341°

RW26

SAYOH2	93.9	42°
OLIVE2	149.6	78°
WASYU3	34.9	292°
TAROH3	91.1	325°
KTE3N	33.3	341°

STAR starting points		distance	inbound direction
ALL	KTE	29.6	237°
	POPAI	29.6	237°
RW26			

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only