

RJSF - Sukagawa - Fukushima

Airport details

State	Fukushima Prefecture
Country	Japan
Region	RJ
Elevation	1220ft (372m)
Timezone	GMT +9
Coordinates	37.21936, 140.43109
Type	land
ICAO code	RJSF
IATA code	FKS
FAA code	n/a

Runway info

Runway 01 / 19	
length	2505m (8219ft)
bearing	3° / 183°
width	60m (197ft)
surface	asphalt
blast zone	60m (197ft) / 60m (197ft)

Communication

Fukushima Fukushima TWR	118.050
Fukushima Fukushima TWR	126.200
Fukushima Fukushima TWR	118.050
Fukushima Fukushima TWR	126.200
Fukushima Fukushima TWR	118.050
Fukushima Fukushima TWR	126.200
Fukushima Fukushima TWR	118.050
Fukushima Fukushima TWR	126.200

Approach frequencies

ILS-cat-I	01	110.5	18.00mi
3° GS	01	110.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
FKE	FUKUSHIMA VOR/DME	0.4	50.4°	113.45
IXE	IWAKI VOR/DME	26.3	97.3°	117.70
GOT	DAIGO TACAN	28.7	189.7°	115.30

JDT	UTSUNOMIYA TACAN	49.9	218.3°	112.15
JD	NIKKO (UTSUNOMIYA) NDB	51.7	217.8°	389
SDE	SENDAI VOR/DME	59.9	28°	116.30

Departure and arrival routes

Transition altitude	14000ft
Transition level	14000ft

SID end points	distance	outbound direction
RW01		
SOUTH1, NASNO3	23.6	218°
FKE2R, WEST1	16.4	301°
RW19		
NASNO3, SOUTH1	23.6	218°
FKE2R, WEST1	16.4	301°

STAR starting points	distance	inbound direction
ALL		
OKUJI	27.2	10°
SOUMAS, WAKAHS	28.7	10°
SOUMAN, WAKAHN	20.4	208°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
OKUJI	OKUJI	VHF	left	241 (61)°	> 8000ft	DME 5.4mi	220

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only