

SARF - Formosa

Airport details

State	Formosa
Country	Argentina
Region	SA
Elevation	193ft (59m)
Timezone	GMT -3
Coordinates	-26.21278, -58.22805
Type	land
ICAO code	SARF
IATA code	FMA
FAA code	n/a

Runway info

Runway 04 / 22	
length	1805m (5922ft)
bearing	27° / 207°
width	30m (100ft)
surface	asphalt
blast zone	20m (66ft) / 20m (66ft)

Communication

FORMOSA TWR	119.100
FORMOSA TWR	119.000
FORMOSA TWR	119.100
FORMOSA TWR	119.000
FORMOSA TWR	119.100
FORMOSA TWR	119.000
FORMOSA TWR	119.100
FORMOSA TWR	119.000

Approach frequencies

ILS-cat-I	22	110.9	18.00mi
3° GS	22	110.9	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
FSA	FORMOSA VOR/DME	0.2	53.3°	115.60
VAS	ASUNCION VOR/DME	69.5	36°	115.90

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only