

# SARP - Posadas

---

## Airport details

State	Misiones
Country	Argentina
Region	SA
Elevation	430ft (131m)
Timezone	GMT -3
Coordinates	-27.39252, -55.97283
Type	land
ICAO code	SARP
IATA code	PSS
FAA code	n/a

## Runway info

Runway 01 / 19	
length	2259m (7411ft)
bearing	359° / 179°
width	30m (98ft)
surface	asphalt
blast zone	23m (75ft) / 23m (75ft)

## Communication

Posadas TWR/APP	120.100
Posadas TWR/APP	118.500
Posadas TWR/APP	120.100
Posadas TWR/APP	118.500
Posadas TWR/APP	120.100
Posadas TWR/APP	118.500
Posadas TWR/APP	120.100
Posadas TWR/APP	118.500

## Approach frequencies

ILS-cat-I	19	109.9	18.00mi
3° GS	19	109.9	18.00mi

## Nearby beacons

code	identifier	dist	bearing	frequency
POS	POSADAS VOR/DME	0.4	28.5°	114.90
P	LIBERADOR GRAL D JOSE DE SAN M NDB	0.8	169.1°	307
VEN	ENCARNACION VOR/DME	12.1	40.2°	116.90

# Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only