

# SBAR - Aracaju - Santa Maria Airport

---

## Airport details

State	Sergipe
Country	Brazil
Region	SB
Elevation	20ft (6m)
Timezone	GMT -3
Coordinates	-10.98528, -37.07333
Type	land
ICAO code	SBAR
IATA code	AJU
FAA code	n/a

## Runway info

Runway 11 / 29	
length	2787m (9144ft)
bearing	92° / 272°
width	45m (148ft)
surface	asphalt
displacement threshold	585m (1919ft) / 0m (0ft)
blast zone	0m (0ft) / 55m (180ft)

## Communication

Santa Maria Airport TWR	118.800
Santa Maria Airport TWR	118.800
Santa Maria Airport TWR	118.800
Santa Maria Airport TWR	118.800
Santa Maria Airport APP	119.000
Santa Maria Airport APP	120.300
Santa Maria Airport APP	120.300
Santa Maria Airport APP	119.000
Santa Maria Airport APP	120.300
Santa Maria Airport APP	119.000
Santa Maria Airport APP	119.000
Santa Maria Airport APP	120.300

## Nearby beacons

code	identifier	dist	bearing	frequency
ARU	CAJU (ARACAJU) VOR/DME	0.3	309.6°	115.40

## Departure and arrival routes

Transition altitude 4000ft  
Transition level 40ft

<b>SID end points</b>	<b>distance</b>	<b>outbound direction</b>
RW12		
VUGR1A, ORAG1A, SIMA1A	50.2	37°
DEND1A	58.4	41°
GATU1A	74.7	188°
ATAR1A	69.0	204°
RW30		
ORAG1B	50.2	37°
DEND1B	58.4	41°
PULU1A	74.7	188°
ATAR1B	69.0	204°

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only