

SBYS - Pirassununga - Campo Fontenelle

Airport details

State	São Paulo
Country	Brazil
Region	SB
Elevation	1964ft (599m)
Timezone	GMT -3
Coordinates	-21.97524, -47.33942
Type	land
ICAO code	SBYS
IATA code	QPS
FAA code	n/a

Runway info

Runway 02L / 20R	
length	2117m (6946ft)
bearing	360° / 180°
width	45m (148ft)
surface	asphalt
Runway 02C / 20C	
length	2117m (6946ft)
bearing	360° / 180°
width	45m (148ft)
surface	asphalt
Runway 02R / 20L	
length	1908m (6260ft)
bearing	360° / 180°
width	45m (148ft)
surface	asphalt

Communication

Campo Fontenelle GND	121.900
Campo Fontenelle GND	121.900
Campo Fontenelle GND	121.900
Campo Fontenelle GND	121.900
Campo Fontenelle ACADEMIA TWR	122.800
Campo Fontenelle ACADEMIA TWR	118.300
Campo Fontenelle ACADEMIA TWR	118.300
Campo Fontenelle ACADEMIA TWR	122.800
Campo Fontenelle ACADEMIA TWR	118.300
Campo Fontenelle ACADEMIA TWR	122.800
Campo Fontenelle ACADEMIA TWR	122.800
Campo Fontenelle ACADEMIA TWR	118.300

Campo Fontenelle ACADEMIA APP	120.100
Campo Fontenelle ACADEMIA APP	122.400
Campo Fontenelle ACADEMIA APP	120.100
Campo Fontenelle ACADEMIA APP	122.400
Campo Fontenelle ACADEMIA APP	122.400
Campo Fontenelle ACADEMIA APP	120.100
Campo Fontenelle ACADEMIA APP	120.100
Campo Fontenelle ACADEMIA APP	122.400

Approach frequencies

ILS-cat-I	02C	109.3	18.00mi
3° GS	02C	109.3	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
PIR	PIRASSUNUNGA VOR/DME	0.6	208.6°	115.80
PSN	PIRASSUNUNGA NDB	0.6	169.9°	310
RCL	RIO CLARO NDB	30	206.1°	280
PCL	POCOS (POCOS DE CALDAS) NDB	43.9	79.8°	415
AAQ	ARARAQUARA NDB	45.6	281.4°	205
RPR	RIBEIRAO (RIBEIRAO PRETO) VOR/DME	55.4	332.6°	115.60
RPR	RIBEIRAO (RIBEIRAO PRETO) NDB	55.6	332.3°	330
IK	BENTO (CAMPINAS) NDB	59.4	172.1°	370
BGC	BRAGANCA (BRAGANCA PAULIS VOR/DME)	72.5	141.7°	116.20

Departure and arrival routes

Transition altitude 7000ft

SID end points	distance	outbound direction
RW02 (ALL)		
NIMPU	38.9	6°
EGBAL	70.6	22°
ILVIV	104.8	64°
MUDRU	68.8	79°
MOLVA	97.2	89°
OPRUT	54.8	93°
NILPI	35.5	99°
LIVED	54.5	131°
BOLIN	46.6	131°
PADAV	54.3	195°
RCL	30.0	206°
MOXAV	68.7	259°
AAQ	45.6	281°
RPR, KALU	55.4	333°

RW02C

RW20 (ALL)	GIBM1A	101.4	341°
	NIMPU	38.9	6°
	EGBAL	70.6	22°
	ILVIV	104.8	64°
	MUDRU	68.8	79°
	MOLVA	97.2	89°
	OPRUT	54.8	93°
	NILPI	35.5	99°
	BOLIN	46.6	131°
	LIVED	54.5	131°
	PADAV	54.3	195°
	RCL	30.0	206°
	MOXAV	68.7	259°
	AAQ	45.6	281°
KALU, RPR	55.4	333°	
RW20C			
	KAMU1A	101.4	341°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only