

SDIA - São Paulo - Ltau Boavista

Airport details

State	São Paulo
Country	Brazil
Region	
Elevation	769ft (234m)
Timezone	GMT -3
Coordinates	-23.54583, -46.62972
Type	helipad
ICAO code	SDIA
IATA code	n/a
FAA code	n/a

Communication

No airport communication available for SDIA

Nearby beacons

code	identifier	dist	bearing	frequency
CGO	CONGONHAS (SAO PAULO) VOR/DME	5	196.9°	116.90
IG	TUCA (SAO PAULO) NDB	5.9	33.9°	410
DAD	DIADEMA (SAO PAULO) NDB	9.7	169.9°	200
BCO	BONSUCESSO (SAO PAULO) VOR/DME	15.8	60.2°	116
STN	SANTANA (SAO PAULO TMA) VOR/DME	16.5	281.2°	114.30
EMB	EMBUGUACU (SAO PAULO) NDB	20.9	211.4°	525
RDE	REDE (SAO PAULO) VOR/DME	21.4	163.6°	116.70
BGC	BRAGANCA (BRAGANCA PAULIS VOR/DME	35.8	5.7°	116.20
SCB	SOROCABA (SAO PAULO TMA) VOR/DME	41.2	272.9°	115.20
CPN	CAMPINAS VOR/DME	42.4	317°	112
SCP	SAO JOSE (SAO JOSE DOS CA VOR/DME	46.3	67.8°	115.40
IK	BENTO (CAMPINAS) NDB	47.4	315.6°	370

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only