

SDWH - José Bonifácio - Fazenda Avanhandava

Airport details

State	São Paulo
Country	Brazil
Region	SB
Elevation	1443ft (440m)
Timezone	GMT -3
Coordinates	-21.18865, -49.93609
Type	land
ICAO code	SDWH
IATA code	n/a
FAA code	n/a

Runway info

Runway 01 / 19	
length	1505m (4938ft)
bearing	357° / 177°
width	30m (98ft)
surface	asphalt
blast zone	0m (0ft) / 50m (164ft)

Communication

No airport communication available for SDWH

Nearby beacons

code	identifier	dist	bearing	frequency
ARA	ARACATUBA NDB	27.6	275.7°	265
JRP	RIO PRETO(SAO JOSE DO RIO PRET NDB	37.3	54.6°	420

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only