

SILV - Guarulhos - Locar

Airport details

State	São Paulo
Country	Brazil
Region	
Elevation	829ft (253m)
Timezone	GMT -3
Coordinates	-23.47083, -46.48306
Type	helipad
ICAO code	SILV
IATA code	n/a
FAA code	n/a

Communication

No airport communication available for SILVA

Nearby beacons

code	identifier	dist	bearing	frequency
IG	TUCA (SAO PAULO) NDB	5	275.4°	410
BCO	BONSUCESSO (SAO PAULO) VOR/DME	6.6	56.5°	116
CGO	CONGONHAS (SAO PAULO) VOR/DME	13.3	227.6°	116.90
DAD	DIADEMA (SAO PAULO) NDB	15.5	206.7°	200
STN	SANTANA (SAO PAULO TMA) VOR/DME	24.2	267.8°	114.30
RDE	REDE (SAO PAULO) VOR/DME	25.3	186.1°	116.70
EMB	EMBUGUACU (SAO PAULO) NDB	29.2	221.2°	525
BGC	BRAGANCA (BRAGANCA PAULIS) VOR/DME	31.5	350.5°	116.20
SCP	SAO JOSE (SAO JOSE DOS CA) VOR/DME	37.2	69.1°	115.40
CPN	CAMPINAS VOR/DME	45.1	305.5°	112
SCB	SOROCABA (SAO PAULO TMA) VOR/DME	49.3	267.6°	115.20
IK	BENTO (CAMPINAS) NDB	50.3	305.4°	370
TBE	TAUBATE NDB	59.1	66.2°	430
TAU	TAUBATE VOR/DME	59.5	65.8°	112.60

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only