

SJTW - Igarassu - Centauro

Airport details

State	Pernambuco
Country	Brazil
Region	
Elevation	20ft (6m)
Timezone	GMT -3
Coordinates	-7.81806, -34.91778
Type	helipad
ICAO code	SJTW
IATA code	n/a
FAA code	n/a

Communication

No airport communication available for SJTW

Nearby beacons

code	identifier	dist	bearing	frequency
YGA	DME	2.1	137.7°	112.90
IF	IBURA (RECIFE) NDB	17.7	182.6°	220
REC	RECIFE VOR/DME	19.1	181.7°	116.90
VSA	DE SANTO ANTAO DME	27.9	232°	113.70
JPS	PESSOA DME	40.3	357.4°	114
JPS	JOAO PESSOA NDB	40.7	357°	320
CPG	CAMPINA GRANDE NDB	66.8	299.5°	230

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only