

SNSW - Soure

Airport details

| | |
|-------------|---------------------|
| State | Pará |
| Country | Brazil |
| Region | SB |
| Elevation | 41ft (12m) |
| Timezone | GMT -3 |
| Coordinates | -0.69766, -48.51962 |
| Type | land |
| ICAO code | SNSW |
| IATA code | SFK |
| FAA code | n/a |

Runway info

| | |
|----------------|---------------------------|
| Runway 06 / 24 | |
| length | 1104m (3622ft) |
| bearing | 40° / 220° |
| width | 31m (102ft) |
| surface | asphalt |
| blast zone | 60m (197ft) / 60m (197ft) |

Communication

No airport communication available for SNSW

Nearby beacons

| code | identifier | dist | bearing | frequency |
|-------------|-------------------|-------------|----------------|------------------|
| BEL | BELEM VOR/DME | 41.3 | 176.5° | 117.30 |

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only