

SPRU - Trujillo

Airport details

State	La Libertad
Country	Peru
Region	SP
Elevation	104ft (32m)
Timezone	GMT -5
Coordinates	-8.08171, -79.10865
Type	land
ICAO code	SPRU
IATA code	TRU
FAA code	n/a

Runway info

Runway 02 / 20	
length	3040m (9974ft)
bearing	17° / 197°
width	44m (145ft)
surface	asphalt
blast zone	62m (203ft) / 64m (210ft)

Communication

Trujillo RDO	126.900
Trujillo RDO	126.900
Trujillo RDO	126.900
Trujillo RDO	126.900
Trujillo TWR	118.700
Trujillo TWR	118.700
Trujillo TWR	118.700
Trujillo TWR	118.700

Approach frequencies

ILS-cat-I	02	109.7	18.00mi
3° GS	02	109.7	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
TRU	TRUJILLO VOR/DME	0.4	213.3°	116.30
MAR	CAJAMARCA NDB	67.4	33.2°	300

Departure and arrival routes

Transition altitude 4500ft

SID end points	distance	outbound direction
RW20		
REL01F	67.4	33°
VATE2F	49.7	63°
ESMI1A	72.8	151°
ESMI1B	50.4	151°

STAR starting points	distance	inbound direction
RW02		
VUGAL1	75.9	349°
RW20		
REL01A	56.7	213°
VATE2A	49.7	243°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only