

# SVDW - Ciudad Piar

---

## Airport details

|             |                    |
|-------------|--------------------|
| State       | Bolivar State      |
| Country     | Venezuela          |
| Region      | SV                 |
| Elevation   | 876ft (267m)       |
| Timezone    | GMT -4             |
| Coordinates | 7.49222, -63.27000 |
| Type        | land               |
| ICAO code   | SVDW               |
| IATA code   | n/a                |
| FAA code    | n/a                |

## Runway info

|                |                |
|----------------|----------------|
| Runway 07 / 25 |                |
| length         | 1605m (5266ft) |
| bearing        | 74° / 254°     |
| width          | 40m (131ft)    |
| surface        | asphalt        |

## Communication

No airport communication available for SVDW

## Nearby beacons

| code | identifier             | dist | bearing | frequency |
|------|------------------------|------|---------|-----------|
| GRY  | TOCOMITA NDB           | 19   | 35.4°   | 255       |
| CBL  | CIUDAD BOLIVAR VOR/DME | 40.8 | 337.3°  | 115.10    |
| GNA  | GUAYANA VOR/DME        | 57   | 32.8°   | 114.70    |

## Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only