

UKLI - Ivano-frankivsk - Ivano Frankivsk Intl

Airport details

State	Ivano-Frankivsk Oblast
Country	Ukraine
Region	UK
Elevation	916ft (279m)
Timezone	GMT +2
Coordinates	48.88588, 24.70352
Type	land
ICAO code	UKLI
IATA code	IFO
FAA code	n/a

Runway info

Runway 10 / 28	
length	2494m (8182ft)
bearing	99° / 279°
width	44m (144ft)
surface	concrete
blast zone	45m (148ft) / 45m (148ft)

Communication

Ivano Frankivsk Intl FRANKO START	124.000
Ivano Frankivsk Intl FRANKO TWR	118.300
Ivano Frankivsk Intl FRANKO START	124.000
Ivano Frankivsk Intl FRANKO TWR	118.300
Ivano Frankivsk Intl FRANKO START	124.000
Ivano Frankivsk Intl FRANKO TWR	118.300
Ivano Frankivsk Intl FRANKO START	124.000
Ivano Frankivsk Intl FRANKO TWR	118.300
Ivano Frankivsk Intl FRANKO APP	127.300
Ivano Frankivsk Intl FRANKO APP	127.300
Ivano Frankivsk Intl FRANKO APP	127.300
Ivano Frankivsk Intl FRANKO START	128.500
Ivano Frankivsk Intl FRANKO APP	127.300
Ivano Frankivsk Intl FRANKO START	128.500
Ivano Frankivsk Intl FRANKO START	128.500
Ivano Frankivsk Intl FRANKO START	128.500

Nearby beacons

code	identifier	dist	bearing	frequency
------	------------	------	---------	-----------

IVF	IVANO-FRANKIVSK VOR/DME	0.4	261.9°	114.20
FN	IVANO-FRANKIVSK NDB	0.6	121.9°	598
LIV	LVIV VOR/DME	62.9	320.9°	115.50

Departure and arrival routes

Transition altitude 10007ft

SID end points	distance	outbound direction
RW10		
SOLN8K	36.8	59°
ILTU8K	34.4	74°
GOTR8K	35.3	88°
POBE3K	31.4	102°
BUKO8K	75.1	127°
TAKO3K	63.6	257°
KOKU3K	56.4	301°
KUSA8K	28.6	336°
RW28		
SOLN8L	36.8	59°
ILTU8L	34.4	74°
GOTR8L	35.3	88°
POBE3L	31.4	102°
BUKO8L	75.1	127°
TAKO3L	63.6	257°
KOKU3L	56.4	301°
KUSA8L	28.6	336°

STAR starting points	distance	inbound direction
RW10		
TAKO3M	63.6	77°
KOKU3M	56.4	121°
KUSA9M	28.6	156°
SOLN8M	36.8	239°
ILTU8M	34.4	254°
GOTR8M	35.3	268°
POBE3M	31.4	282°
BUKO8M	75.1	307°
RW28		
TAKO3N	63.6	77°
KOKU3N	56.4	121°
KUSA9N	28.6	156°
SOLN8N	36.8	239°
ILTU8N	34.4	254°
GOTR8N	35.3	268°
POBE3N	31.4	282°
BUKO8N	75.1	307°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
BUKO8M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
BUKO8N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
GOTR8M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
GOTR8N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
ILTU8M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
ILTU8N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
KOKU3M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
KOKU3N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
KUSA9M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
KUSA9N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
POBE3M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
POBE3N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
SOLN8M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
SOLN8N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
TAKO3M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
TAKO3N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
VI3M	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules
VI3N	IVF	NDB	right	114 (294)°	> 2630ft	1.0min timed	ICAO rules

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only